

INSTRUCTION SHEET

HIGH PERFORMANCE SWAY BAR SET

G2-2005 1998-2003 GS300/GS400/GS430 (JZS160/UZS160/UZS161)

Congratulations on your purchase of this high performance sway bar set! When properly installed, this kit will dramatically improve the handling of your vehicle. The polyurethane bushing construction will not deteriorate over time or with harsh environmental conditions.

INSTALLATION INSTRUCTIONS

1. Remove original sway bar brackets, sway bar bushings and sway bars as per factory service manual instructions.
2. Remove front upper sway bar mounting bracket bolts (see below), and re-install bolts using Loctite. Torque bolts to 36 lb-ft.
3. **IMPORTANT! - Grease the insides of the new bushings with supplied grease before installation! Approximately 1 tube per bushing is recommended.**
4. Install new bushings onto sway bars.
5. Install front sway bar using original sway bar bushing brackets and bolts using Loctite. Torque bolts to 21 lb-ft.
6. Re-attach end link nuts and bolts and torque to 41 lb-ft.
7. **Reverse rear stabilizer bar link by removing it and turning it so that the stud is facing towards the outside of the vehicle.** Loosely re-install all hardware.
8. Install rear sway bar using original sway bar bushing brackets and bolts using Loctite. Torque bolts to 13 lb-ft.
9. Torque remaining hardware to factory specifications.
(End link nuts 48 lb-ft, lower link nuts 22 lb-ft, lower shock nuts 81 lb-ft).



Rear Bar Adjustment

