

POLYURETHANE OEM SWAY BAR BUSHING SET

L1-2008 1990-1992 LS400 (UCF10)
L1-2008A 1993-1994 LS400 with Air Suspension (UCF10)
L1-2008B 1993-1994 LS400 without Air Suspension (UCF10)

Congratulations on your purchase of this high performance sway bar bushing set! When properly installed, these bushings will improve the handling of your vehicle with no adverse effects on ride quality or driveability. The polyurethane construction will not deteriorate over time or with harsh environmental conditions.

INSTALLATION INSTRUCTIONS

1. Remove original sway bar bushing brackets.
2. Remove original rubber sway bar bushings from sway bars.
(Removal of sway bar from the vehicle is not necessary).
3. **IMPORTANT! Grease the insides of the new bushings with supplied grease before installation!**
5. Install new bushings onto sway bars.
6. Reinstall original sway bar bushing brackets and torque bolts to factory specifications.
(Front 21 lb-ft, rear 21 lb-ft) Loctite is recommended.
7. Check end link bolts for proper torque specifications.
(Front 70 lb-ft, rear 26 lb-ft) Loctite is recommended.